


Quick Start Guide




Electronic pdf files of Nordson EFD manuals are also available at www.nordsonefd.com




Unpack the unit. Now is a good time to activate the warranty online at www.nordsonefd.com/warranty/controllers.

1. Mount the VM8040 and input power supply. The ValveMate™ can be mounted either over or under a cabinet or panel mounted using the bezel mount (included).



2. Install and connect the power supply. Connect the power supply cord to the ValveMate input connector. Secure with locking ring.



3. Install the air pressure regulator and air solenoids.

- a. Connect the plant air supply to the inlet of the filter regulator.
- b. Connect the solenoid cable between the solenoid and VM8040.

4. Connect the low air pressure sensor and tank low level switches (if low level float provided with reservoir) to ALARM IN.

NOTE: Wire additional normally closed alarm sensors in series and connect to the ALARM IN +/- terminals. If no alarm switch is used, the ALARM IN +/- terminals must have a jumper installed to disable the ALARM feature.

5. Connect the initiate I/O to the host machine control circuitry or to the bench initiate switch.


6. Install the spray valves:

- a. Mount the valves using appropriate mounting hardware.
- b. Connect the valve control air hoses to the appropriate solenoid outlets.

7. Connect the fluid reservoir:

- a. Connect the fluid reservoir air pressure regulator to the plant air supply using the air hose and fitting supplied.
- b. Connect the reservoir fluid lines to the dispense valves.

Fill the fluid reservoir and secure the cover.



8.

Final checklist:


- a. Air pressure to solenoid pack is set to 5.5 bar (80 psi).
- b. For spray valves, nozzle air regulator is set to 0 bar (0 psi).
- c. Solenoids and I/O are wired correctly.
- d. Valves and fluid reservoir are properly connected.
- e. Power to the ValveMate is ON, and indicator lamps and LED are lit.

9.

Set the tank pressure to 0.35 bar (5 psi) for low viscosity fluids and 1.03 bar (15 psi) for higher viscosity fluids.


10.

Set the spray valve stroke adjustment to 1/2 turn open. This is a starting point only.







11.

Place a container under the spray valve(s):

- a. Using the MODE  button, place the VM8040 in **PURGE** mode.
- b. Press the **PURGE** button and hold until fluid flows and fluid lines are free of air. Then set the flow rate using the valve stroke setting and tank air pressure. Avoid high tank pressures with low stroke settings. Set the flow rate by counting drops to about one per second as a starting point.

12.

Adjusting the spray:

- a. Set the nozzle air pressure regulator to 0.69 bar (10 psi).
- b. Press the **PURGE** button and observe the spray pattern.
- c. Using the spray valve stroke adjustment and tank air pressure, increase or decrease settings to arrive at the desired spray pattern.
- d. Using the MODE  button, place the controller in **SETUP** mode.
- e. Press the SEL  button repeatedly until all valve indicator lights are lit.
- f. Enter a spray time of .050 seconds by pressing the up or down arrow next to the LED screen.
- g. With the container still under the valve(s), press the **CYCLE**  button to test the deposit amount.
- h. Increase or decrease the valve open time to arrive at the correct deposit size. To equalize all valves, press the SEL  button to highlight individual valve channel(s) and use the valve open time to equalize the outputs.

TIP

Valve open time is the primary control of deposit size. It is normal to end with different time settings for each valve.



For Nordson EFD sales and service in over 40 countries, contact Nordson EFD or go to www.nordsonefd.com.

Global

800-556-3484; +1-401-431-7000
info@nordsonefd.com

Europe

00800 7001 7001
infoefd.europe@nordsonefd.com

Asia

China: +86 (21) 3866 9006; china@nordsonefd.com
India: +91 80 4021 3600; india@nordsonefd.com
Japan: +81 03 5762 2760; japan@nordsonefd.com
Korea: +82-31-736-8321; korea@nordsonefd.com
SEAsia: +65 6796 9522; sin-mal@nordsonefd.com

The Wave Design is a trademark of Nordson Corporation.
©2021 Nordson Corporation 7022122 v012821