


725HF-SS High Flow Piston Valve

Maintenance & Parts Guide



IMPORTANT!
Save this Sheet.

Forward to
Maintenance or
Tool Crib Supervisors

Electronic pdf files of Nordson EFD
manuals are also available at
www.nordsonefd.com



Valve Disassembly

CAUTION

To prevent damage, the valve must be disassembled starting at the fluid outlet end of the valve.

1. Put the threaded rod in the mounting hole.
2. Remove the outlet cap.
3. Remove the sealing head. *
4. With a wrench on the flats of the air cylinder body, turn to loosen the fluid body.
5. Remove the fluid body. *
6. Remove the input air hose from the push-in fitting on the air cap.
7. Insert a 1/8" hex wrench through the air inlet hole in the cap and turn the shaft locking screw out two turns. *
8. Using the hex on the shaft, unthread the shaft, and remove the shaft and diaphragm. *
9. Unscrew the air cylinder cap from the air cylinder body. *
10. Remove the piston and spring.

NOTE: Before reassembling valve, clean all parts and replace O-rings, the sealing head, and the diaphragm. Inspect for damaged threads, and check piston pins for straightness and the fluid body seat for pitting.

Maintenance Tools:

- 1/8" hex wrench
- 1/4" flat-tip screwdriver
- 3/8" box wrench
- 7/8" open-end wrench
- 8" adjustable wrench
- 1/4" NPT male pipe or rod

Valve Reassembly

CAUTION

Do not thread fluid inlet fittings too far into the valve. Doing so can obstruct the piston shaft, causing leakage, poor dispensing performance, and damage to the valve.

Reassemble the valve in the reverse order of disassembly. Lubricate the parts indicated with Nye Lubricant #865, included in the General Maintenance Kit.

*Parts that require a specific torque during valve reassembly:

Step	Part	N•m	in.-lb / ft-lb
3	Sealing head screw	1.69 N•m	15 in.-lb
5	Stainless steel fluid body	10.8–13.6 N•m	8–10 ft-lb
7	Shaft locking screw	2.82 N•m	25 in.-lb
8	Shaft	1.69 N•m	15 in.-lb
9	Air cylinder cap	10.8 N•m	8 ft-lb

Replacement Parts

**Included in the General Maintenance Kit (#7021019)


Part #	Description
7021020	725HF-SS Valve
7021019	General Maintenance Kit Includes air cylinder and outlet cap O-rings, diaphragm, sealing head with screw, spring, and lubricant.



Assembly of piston, diaphragm, and shaft



Nye gel lubricant **
1 gram foil packet



Troubleshooting Guide

No fluid flow

- If valve operating air pressure is too low, the valve will not open. Increase air pressure to 4.8 bar (70 psi) minimum.
- The reservoir air pressure may not be high enough. Increase pressure.
- The dispensing nozzle may be clogged. Replace nozzle.
- Fluid may have solidified in the fluid body. Clean the fluid body.

Fluid drools after the valve closes, eventually stopping

- This is caused when air is trapped in the outlet section of the fluid body or the fluid has entrapped air. The air will expand after the valve closes, causing extrusion until the air reaches atmospheric pressure.
- Purge the valve by dispensing at a steady flow until clear. If a small tip is used, it may be necessary to remove the tip while purging to obtain sufficient flow to carry the air down through the tip adapter.
- If the fluid has entrapped air, the material must be degassed before dispensing.

NOTE: For stripes and lines, input air pressure can be lowered to eliminate opening surge.

Fluid drips at a steady rate after the valve closes

- A steady drip indicates failure of the sealing head to close fully due to particle build-up or wear. In either case, replace the sealing head in accordance with the maintenance instructions.
- Fluid leakage can also occur when a fluid inlet fitting is threaded too far into the valve, thus obstructing the piston shaft. Ensure that the fluid inlet fitting is properly installed.

Valve responds slowly when opening and closing

- Valve response is related to control air hose length and size. The valve is supplied with 1.5 m (5 ft) of 4 mm (5/32") tubing attached. Any additional length or size change will affect response time. Check to be sure the length and size have not been changed.

Fluid flows out of the drain hole

- Fluid flowing out of the drain hole indicates a ruptured diaphragm. Replace in accordance with the maintenance instructions.

Inconsistent deposits

- Inconsistent deposits can result if the air pressure controlling the valve and/or supplying the reservoir is fluctuating or if the valve operating pressure is less than 4.8 bar (70 psi). Check to be sure air pressures are constant and the valve operating pressure is 4.8 bar (70 psi).
- The time the valve is open must be constant. Check to be sure the valve controller is providing a consistent output.



For Nordson EFD sales and service in over 40 countries, contact Nordson EFD or go to www.nordsonefd.com.

Global

800-556-3484; +1-401-431-7000
info@nordsonefd.com

Europe

00800 7001 7001
infoefd.europe@nordsonefd.com

Asia

China: +86 (21) 3866 9006; china@nordsonefd.com
 India: +91 80 4021 3600; india@nordsonefd.com
 Japan: +81 03 5762 2760; japan@nordsonefd.com
 Korea: +82-31-736-8321; korea@nordsonefd.com
 SEAsia: +65 6796 9522; sin-mal@nordsonefd.com