

ProcessMate™ 6500 Temperature Control Unit

Quick Start Guide

Electronic pdf files of Nordson EFD manuals are also available at www.nordsonefd.com.

Easy 7-Step Setup

Follow these steps to get your ProcessMate Temperature Control System ready for operation.



Unpack the Unit / Warranty

1

- Use the checklist enclosed with the ProcessMate to identify all items. If there is any discrepancy, please call us immediately.
- Now is a good time to activate your extended One Year No-Fault Warranty. Register the warranty online at www.nordsonefd.com/warranty/dispensers/one.

Connect Power

2

- Connect the power plug to the power pack. The unit is shipped with a USA-compatible plug and three international plugs. Attach the correct plug to match local power outlets.
- Connect the power cord into the back of the ProcessMate.
- Connect the power cord into your local power source.



Connect Air Input

3

NOTE: Clean, dry, filtered factory air is necessary to meet warranty requirements. If your air supply is not filtered, order the EFD five-micron filter regulator (P/N 7002002).

- Push one end of the air input hose into the input fitting on the back of the ProcessMate.
- Connect the other end of the hose to your plant air supply.
- Set plant air supply within 5.5 to 6.9 bar (80 to 100 psi).
- **DO NOT exceed 7.5 bar (110 psi), or damage to the unit may occur.**



Connect Thermocouple

4

- Plug the K-type thermocouple lead into the back panel of the ProcessMate.
- Connect the other end of the lead to process hardware.

Option: Can route lead with either air line tubing inside insulation. See Step 5.

NOTE: Longer thermocouple leads may be used when required. These are available from a variety of sources in many lengths. Only K-Type thermocouple leads should be used with the ProcessMate. Using a different type will result in incorrect temperatures.



Attach Temp. Control Feed Lines

5

- Slide the insulation over the cold feed line.
- Slide the insulation over the hot feed line.

Option: Can route thermocouple lead with either hot or cold feed line.

- Insert the cold feed line into the cold process fitting.
- Insert the hot feed line into the hot process fitting.




Connect Exhaust Mufflers

6

- Insert a muffler into each exhaust port for both cold and hot feed exhausts.

NOTE: Tubing can be purchased as an accessory to route for remote exhaust in lieu of mufflers.



Operation

7

- Turn the power switch to the ON position.
- Turn air switch to ADJ AIR. Turn the knob labeled with +/- markings to allow more or less air to reach the desired pressure.
- Press the UP/DOWN button on the front panel display to desired dispensing temperature. (Hold down button for rapid increase / decrease.)



Helpful Hints

See Operating Manual for additional information and frequently asked questions.



For Nordson EFD sales and service in over 40 countries, contact Nordson EFD or go to www.nordsonefd.com.

Global

800-556-3484; +1-401-431-7000
info@nordsonefd.com

Europe

00800 7001 7001
infoefd.europe@nordsonefd.com

Asia

China: +86 (21) 3866 9006; china@nordsonefd.com
India: +91 80 4021 3600; india@nordsonefd.com
Japan: +81 03 5762 2760; japan@nordsonefd.com
Korea: +82-31-736-8321; korea@nordsonefd.com
SEAsia: +65 6796 9522; sin-mal@nordsonefd.com