

ASYMTEK Select Coat® Low Fluid Scale Spares List

A range of spare parts are available to support Nordson Electronics Solutions products, keeping them running at peak performance. Nearly all spare parts are sold as part of a spares kit, with a few exceptions.

How to Locate and Order Spare Parts

If you are referring to the User Manual to complete a procedure, you can search for a *Kit Part Number* or an individual *Part Description* to identify the kit or individual part you need to complete the procedure.

If you have a *part number*, search the Lookup Part Number column in the tables below to identify whether the part is sold in a kit or as an individual part. You will find it in the Spares Kit List table if it's sold in a kit. You will find it in the Individual Part List table if it's sold as an individual part.

To locate a kit or individual part, do the following:

1. Download this file and open it in a browser such as Google Chrome.
2. Use your browser's search feature to search for a *Kit Part Number*, individual *Part Description*, or *part number*.
 - If the part is sold in a spares kit, refer to the corresponding columns in the Spares Kit List table for details about the kit. Use the **Kit Part Number** to order the kit.
 - If the part is sold individually, refer to the corresponding column in the Individual Part List table for details. Use the **Lookup Part Number** to order the part.
3. To request a quote, do the following:
 - Click [here](#).
 - Locate your region and click the **Email link**.
A draft email addressed to the recipient you selected is displayed.
 - In the Subject field, type **New Request for Quote**.
 - In the body of the email, provide the following information:
 - The **Kit Part Number(s)** for the kit(s) you want to order. And the quantity of each kit.
 - The **Lookup Part Number(s)** for the individual part(s) you want to order. And the quantity of each part.
 - The Ship To information: **company name** and **complete shipping address**.
 - Your **name**, **phone number**, and **email address**.
 - Click **Send**.

Spares Kit List

All parts listed in the following table are sold only within kits, not individually. The information in the Lookup Part Number column allows you to locate a part that you previously ordered separately but is now only available as part of a kit. The Quantity column shows the quantity you will receive for each part in a kit.

Kit Name	Kit Part Number	Part Description	Quantity	Lookup Part Number
OPT,SCALE,LOW FLUID LVL,150LBS (SL-1040)	6651370			
		ASSY,SCALE,LOW FLUID,150LBS	1	6651369
		TIE WRAP, 5.5" BLACK	4	7254056
		SCREW, M4 X 0.7, SOCKET CAP,X8	2	388026
		CABLE,SCALE,LOW FLUID,940	1	7218804
		CABLE, ASSY FOR LFS TEST	1	6111709
		CLIP,WIRE HARNESS,1"DIA	2	7226307
OPT,SCALE,LOW FLUID LVL (SL-940)	7216279			
		CLIP,WIRE HARNESS,.500 ID	2	194971
		ASSY,SCALE,LOW FLUID	1	210543
		ASSY,PWR SUPPLY,LOW FLD SCALE	1	210545
		VELCRO,1" WIDTH,BLACK	1 FT	7246604
		CABLE TIE,4",BLACK	5	382767
		TIE WRAP, 5.5" BLACK	4	7254056
		PLATFORM, TIE WRAP MOUNTING	2	387906
		CLIP,WIRE HARNESS,1"DIA	2	7226307
		SCREW, M4 X 0.7, SOCKET CAP,X8	2	388026
		CABLE-P,POWER JUMPER,INT'L-1M	1	7245455
		CABLE,SCALE,LOW FLUID,940	1	7218804
		CABLE, ASSY FOR LFS TEST	1	6111709

Individual Part List

There are no individually sold items for the Select Coat Low Fluid Scale. All items are sold in kits, and the list of kits is in the Spares Kit List table above.

Part Description	Lookup Part Number
n/a	n/a