

Optimum Ceramic MicroDot Tips

Industry-leading micro dispensing as small as 100 µm



Ceramic MicroDot tips can produce precise micro-deposits as small as 100 µm.

Optimum® Ceramic MicroDot™ tips feature a ceramic cannula that can be used with fine particle-filled materials. They are ideal for dispensing UV-cure adhesives and other assembly fluids commonly used in the electronic and life science industries. The ceramic MicroDot tip can also withstand repeated cleaning and flushing using acetone.

Ceramic MicroDot tip hubs are manufactured with stainless steel. Stainless steel hubs are robust and long-lasting, and are machined to extremely tight tolerances.

Features

- Ceramic cannula, available with stainless steel hubs
- Tapered inner diameter reduces back pressure and ensures consistent fluid deposit and cutoff
- Excellent tip-to-tip consistency for more repeatable dispensing results
- Outstanding chemical compatibility for a wide range of fluids

Benefits

- Reduced back pressure to ensure full deposit is dispensed
- Longer dispense life, even when used to dispense abrasive, particle-filled materials
- Deposits as small as 100 µm for critical applications

Part #	Gauge	Description	ID mm / in	Qty
7364386	37	Ceramic tip, SS hub, for use with luer lock connections	0.05 / 0.002	1 pc



more info



For Nordson EFD sales and service in over 40 countries, contact Nordson EFD or go to www.nordsonefd.com.

800-556-3484; +1-401-431-7000

info@nordsonefd.com

infoefd.europe@nordsonefd.com

asia@nordsonefd.com

©2024 Nordson Corporation v110124